Battery saving mode all the time

Sailfish OS (5.0) UI allows to start the battery saving mode / power saving mode at will from the Battery setting menu, and to set a threshold from which the battery saving mode is automatically enabled. This threshold can be chosen between 20%, 15%, 10%, 5%... But not higher than 20%.

Even if this mode isn't saving much battery, if you want to have it set all the time you can use this commands from the Terminal :

```
devel-su pkcon install mce-tools  # to install the package that contains the mcetool command line program
```

```
mcetool --set-psm-threshold=100 --set-power-saving-mode=enabled --set-forced-psm=enable
```

This second line enables the power saving mode and sets it to auto-start from 100%. This way you'll be using your phone in power saving mode all the time except when it is plugged (loading the battery).

This setting is kept even after a reboot, just like if you had a 100% label available in the graphical Battery settings to click on.

This information have been summarized from this discussion : https://forum.sailfishos.org/t/please-add-function-for-automatic-power-saving-mode/7322

Revision #3
Created 11 January 2026 16:25:09 by Siltaar
Updated 23 February 2026 15:14:44 by Siltaar